

- |                     |         |               |
|---------------------|---------|---------------|
| ① Set plate         | ③ Screw | ⑤ Bulb holder |
| ② Battery cartridge | ④ Ring  | ⑥ Reflector   |

**SPECIFICATIONS**

<b>Model</b>	<b>ML702</b>	<b>ML901</b>	<b>ML902</b>	<b>ML903</b>
Bulb .....	7.2 V 0.55 A	9.6 V 0.5 A	9.6 V 0.5 A	9.6 V 0.5 A
Dimensions (L x W x H) .....	283 x 67 x 71 mm (11-1/8" x 2-5/8" x 2-13/16")	254 x 67 x 96 mm (10" x 2-5/8" x 3-3/4")	325 x 67 x 71 mm (12-13/16" x 2-5/8" x 2-13/16")	254 x 77 x 98 mm (10" x 3" x 3-7/8")
Net weight .....	0.3 kg (0.66 lbs)	0.3 kg (0.66 lbs)	0.3 kg (0.66 lbs)	0.3 kg (0.66 lbs)

- Due to the continuing program of research and development, the specifications herein are subject to change without prior notice.
- Note: Specifications may differ from country to country.

**IMPORTANT SAFETY INSTRUCTIONS**

**WARNING:**

When using electric tools, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and personal injury, including the following:

**READ ALL INSTRUCTIONS.**

1. Read this instruction manual and the charger instruction manual carefully before use.
2. This torch/flashlight is not water-proof. Do not use it in damp or wet locations. Do not expose it to rain or snow. Do not wash it in water.
3. A short-circuit can cause a large current flow, overheating, possible burns and even a breakdown.
  - (1) Do not touch the inside of the torch/flashlight head with tweezers, metal tools, etc.
  - (2) Do not touch the battery terminals with any conductive material.
  - (3) Avoid storing the battery cartridge in a container with any metal objects such as nails, coins, etc.
4. Never expose the battery cartridge to flames, fire or great heat. Breakage may cause release of injurious material.
5. Do not disassemble the charger or battery cartridge; take it to a qualified serviceman when service or repair is required. Incorrect reassembly may result in a risk of electric shock or fire.
6. If any problem develops, consult your nearest Makita Service Center or dealer. To maintain product safety and reliability, repairs, maintenance or adjustment should be carried out by Makita Authorized Service Center.

**SAVE THESE INSTRUCTIONS.**

**For USA only  
Recycling the Battery**

The only way to dispose of a Makita battery is to recycle it. The law prohibits any other method of disposal.

**To recycle the battery:**

1. Remove the battery from the tool.
2. a). Take the battery to your nearest Makita Factory Service Center  
or  
b). Take the battery to your nearest Makita Authorized Service Center or Distributor that has been designated as a Makita battery recycling location.
  - Call your nearest Makita Service Center or Distributor to determine the location that provides Makita battery recycling. See your local Yellow Pages under "Tools-Electric".

